

Via stepwise prestressing that not exceeds the adhesives maximum allowed shear stresses, no delamination occurs.

STEPWISE PRESTRESSING

- Force distribution via stepwise prestressing
- No endforces in structural member
- No mechanical anchorages needed

MATERIAL

- Adhesiv epoxy
- Strengthening material are composite materials (FRPs) and in some cases steel

